

Tough-Mark™ Application Instruction



1. Application surface should be uniform and free of cracks or ridges. The ambient temperature should be above 50°F.



2. Apply only to clean dry floors: thoroughly wash, rinse, and allow to dry, completely.



3. Peel back about 2 inches of the liner and start to set in place.



4. Once satisfied with the placement, continue to peel back the liner and position.



5. Cut adjoining pieces at 45° angles and place together to make a corner.



6. For maximum adhesion, use a tamper device with a minimum of a 150-pound load. Tamp in the same direction that the strips were applied. Several passes should ensure adhesion to the surface.



7. Clean Tough-Mark™ strips and shapes with mild cleaning solutions. Do not use commercial strippers or waxing machines.



8. To remove Tough-Mark™ strips and shapes, starting at the edge, use a scraper to break the bond between the strip / shape and the floor. Once the edge is lifted peel back the tape to remove.